



Gelieve de webshop te gebruiken om uw bestelling door te sturen

| Departement: Compacte uitvoering BSPE - BSP <W> - BABA |                                                            |                                      |                                                |
|--------------------------------------------------------|------------------------------------------------------------|--------------------------------------|------------------------------------------------|
| Nr                                                     | Atl                                                        | Omschrijving                         |                                                |
| NBB M-V<br>RE16-<br>R24                                |                                                            | NIPPEL MANN.-VR. BSPE 1"- BSP 1"1/2  | NBB M-V RE16-<br>R20                           |
|                                                        | NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1"- BSP<br>1"1/4        | NBB M-V RE16-R12                     |                                                |
| NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1"- BSP<br>3/4      | NBB M-V<br>RE24-<br>R20                                    |                                      | NIPPEL MANN.-<br>VR. BSPE 1"1/2<br>- BSP 1"1/4 |
| NBB M-V<br>RE20-<br>R16                                |                                                            | NIPPEL MANN.-VR. BSPE 1"1/4 - BSP 1" | NBB M-V RE20-<br>R24                           |
|                                                        | NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1"1/4 -<br>BSP<br>1"1/2 | NBB M-V RE08-R16                     |                                                |
| NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1/2 -<br>BSP 1"     | NBB M-V<br>RE08-<br>R20                                    |                                      | NIPPEL MANN.-<br>VR. BSPE 1/2 -<br>BSP 1" 1/4  |
| NBB M-V<br>RE08-<br>R12                                |                                                            | NIPPEL MANN.-VR. BSPE 1/2 - BSP 3/4  | NBB M-V RE08-<br>R06                           |
|                                                        | NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1/2 -<br>BSP 3/8        | NBB M-V RE04-R08                     |                                                |
| NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1/4 -<br>BSP 1/2    | NBB M-V<br>RE04-<br>R02                                    |                                      | NIPPEL MANN.-<br>VR. BSPE 1/4 -<br>BSP 1/8     |
| NBB M-V<br>RE04-<br>R12                                |                                                            | NIPPEL MANN.-VR. BSPE 1/4 - BSP 3/4  | NBB M-V RE04-<br>R06                           |
|                                                        | NIPPEL<br>MANN.-<br>VR.<br>BSPE<br>1/4 -<br>BSP 3/8        | NBB M-V RE02-R04                     |                                                |

|                                                           |                                                           |                                      |                                             |
|-----------------------------------------------------------|-----------------------------------------------------------|--------------------------------------|---------------------------------------------|
| NIPPEL<br>MANN. -<br>VR.<br>BSPE<br>1/8 -<br>BSP 1/4      | NBB M-V<br>RE02-<br>R06                                   |                                      | NIPPEL MANN. -<br>VR. BSPE 1/8 -<br>BSP 3/8 |
| NBB M-V<br>RE12-<br>R16                                   |                                                           | NIPPEL MANN. -VR. BSPE 3/4 - BSP 1"  | NBB M-V RE12-<br>R24                        |
|                                                           | NIPPEL<br>MANN. -<br>VR.<br>BSPE<br>3/4 -<br>BSP<br>1"1/2 | NBB M-V RE12-R20                     |                                             |
| NIPPEL<br>MANN. -<br>VR.<br>BSPE<br>3/4 -<br>BSP<br>1"1/4 | NBB M-V<br>RE12-<br>R08                                   |                                      | NIPPEL MANN. -<br>VR. BSPE 3/4 -<br>BSP 1/2 |
| NBB M-V<br>RE06-<br>R08                                   |                                                           | NIPPEL MANN. -VR. BSPE 3/8 - BSP 1/2 | NBB M-V RE06-<br>R04                        |
|                                                           | NIPPEL<br>MANN. -<br>VR.<br>BSPE<br>3/8 -<br>BSP 1/4      | NBB M-V RE06-R12                     |                                             |