



Gelieve de webshop te gebruiken om uw bestelling door te sturen

Departement: Inschroefnippel BSPH Instelbaar - BSP - BBAD		
Nr	Atl	Omschrijving
NBB45 MI-M RH16-R16		NIPPEL 45° MANN.- MANN. BSPH 1" - BSPP 1"
NBB45 MI-M RH16-R20		NIPPEL 45° MANN.- MANN. BSPH 1" - BSPP 1"1/4
NBB45 MI-M RH16-R12		NIPPEL 45° MANN.- MANN. BSPH 1" - BSPP 3/4"
NBB45 MI-M RH24-R24		NIPPEL 45° MANN.- MANN. BSPH 1"1/2 - BSPP 1"1/2
NBB45 MI-M RH24-R20		NIPPEL 45° MANN.- MANN. BSPH 1"1/2 - BSPP 1"1/4
NBB45 MI-M RH20-R16		NIPPEL 45° MANN.- MANN. BSPH 1"1/4 - BSPP 1"
NBB45 MI-M RH20-R24		NIPPEL 45° MANN.- MANN. BSPH 1"1/4 - BSPP 1"1/2
NBB45 MI-M RH20-R20		NIPPEL 45° MANN.- MANN. BSPH 1"1/4 - BSPP 1"1/4
NBB45 MI-M RH08-R08		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 1/2
NBB45 MI-M RH08-R04		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 1/4
NBB45 MI-M RH08-R12		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 3/4
NBB45 MI-M RH08-R06		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 3/8
NBB45 MI-M RH08-R10		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 5/8
NBB45 MI-M RH04-R04		NIPPEL 45° MANN.- MANN. BSPH 1/4 - BSPP 1/4
NBB45 MI-M RH04-R02		NIPPEL 45° MANN.- MANN. BSPH 1/4 - BSPP 1/8
NBB45 MI-M RH04-R06		NIPPEL 45° MANN.- MANN. BSPH 1/4 - BSPP 3/8
NBB45 MI-M RH02-R04		NIPPEL 45° MANN.- MANN. BSPH 1/8 - BSPP 1/4
NBB45 MI-M RH02-R02		NIPPEL 45° MANN.- MANN. BSPH 1/8 - BSPP 1/8

NBB45 MI- M RH12- R16		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 1"
NBB45 MI- M RH12- R08		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 1/2
NBB45 MI- M RH12- R12		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 3/4
NBB45 MI- M RH12- R06		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 3/8
NBB45 MI- M RH12- R10		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 5/8
NBB45 MI- M RH06- R08		NIPPEL 45° MANN.- MANN. BSPH 3/8 - BSPP 1/2
NBB45 MI- M RH06- R04		NIPPEL 45° MANN.- MANN. BSPH 3/8 - BSPP 1/4
NBB45 MI- M RH06- R06		NIPPEL 45° MANN.- MANN. BSPH 3/8 - BSPP 3/8
NBB45 MI- M RH10- R08		NIPPEL 45° MANN.- MANN. BSPH 5/8 - BSPP 1/2
NBB45 MI- M RH10- R10		NIPPEL 45° MANN.- MANN. BSPH 5/8 - BSPP 5/8