



Gelieve de webshop te gebruiken om uw bestelling door te sturen

Departement: Inschroefnippel BSPH Instelbaar - BSP - BBAD			
Nr	Atl	Omschrijving	
NBB45 MI-M RH16- R16		NIPPEL 45° MANN.- MANN. BSPH 1" - BSPP 1"	NBB45 MI-M RH16-R20
	NIPPEL 45° MANN.- MANN. BSPH 1" - BSPP 1"1/4	NBB45 MI-M RH16-R12	
NIPPEL 45° MANN.- MANN. BSPH 1" - BSPP 3/4"	NBB45 MI-M RH24- R24		NIPPEL 45° MANN.- MANN. BSPH 1"1/2 - BSPP 1"1/2
NBB45 MI-M RH24- R20		NIPPEL 45° MANN.- MANN. BSPH 1"1/2 - BSPP 1"1/4	NBB45 MI-M RH20-R16
	NIPPEL 45° MANN.- MANN. BSPH 1"1/4 - BSPP 1"	NBB45 MI-M RH20-R24	
NIPPEL 45° MANN.- MANN. BSPH 1"1/4 - BSPP 1"1/2	NBB45 MI-M RH20- R20		NIPPEL 45° MANN.- MANN. BSPH 1"1/4 - BSPP 1"1/4
NBB45 MI-M RH08- R08		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 1/2	NBB45 MI-M RH08-R04
	NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 1/4	NBB45 MI-M RH08-R12	
NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 3/4	NBB45 MI-M RH08- R06		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 3/8

NBB45 MI-M RH08- R10		NIPPEL 45° MANN.- MANN. BSPH 1/2 - BSPP 5/8	NBB45 MI-M RH04-R04
	NIPPEL 45° MANN.- MANN. BSPH 1/4 - BSPP 1/4	NBB45 MI-M RH04-R02	
NIPPEL 45° MANN.- MANN. BSPH 1/4 - BSPP 1/8	NBB45 MI-M RH04- R06		NIPPEL 45° MANN.- MANN. BSPH 1/4 - BSPP 3/8
NBB45 MI-M RH02- R04		NIPPEL 45° MANN.- MANN. BSPH 1/8 - BSPP 1/4	NBB45 MI-M RH02-R02
	NIPPEL 45° MANN.- MANN. BSPH 1/8 - BSPP 1/8	NBB45 MI-M RH12-R16	
NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 1"	NBB45 MI-M RH12- R08		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 1/2
NBB45 MI-M RH12- R12		NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 3/4	NBB45 MI-M RH12-R06
	NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 3/8	NBB45 MI-M RH12-R10	
NIPPEL 45° MANN.- MANN. BSPH 3/4 - BSPP 5/8	NBB45 MI-M RH06- R08		NIPPEL 45° MANN.- MANN. BSPH 3/8 - BSPP 1/2
NBB45 MI-M RH06- R04		NIPPEL 45° MANN.- MANN. BSPH 3/8 - BSPP 1/4	NBB45 MI-M RH06-R06
	NIPPEL 45° MANN.- MANN. BSPH 3/8 - BSPP 3/8	NBB45 MI-M RH10-R08	
NIPPEL 45° MANN.- MANN. BSPH 5/8 - BSPP 1/2	NBB45 MI-M RH10- R10		NIPPEL 45° MANN.- MANN. BSPH 5/8 - BSPP 5/8