



Gelieve de webshop te gebruiken om uw bestelling door te sturen

| Departement: (Inschroef)nippel Mann.-Mann. BSP-Metr. - CEA |     |                                    |
|------------------------------------------------------------|-----|------------------------------------|
| Nr                                                         | Atl | Omschrijving                       |
| NBM M-M<br>R16-M38                                         |     | NIPPEL MANN.-MANN. BSPP 1" - M38   |
| NBM M-M<br>R08-M14                                         |     | NIPPEL MANN.-MANN. BSPP 1/2" - M14 |
| NBM M-M<br>R08-M16                                         |     | NIPPEL MANN.-MANN. BSPP 1/2" - M16 |
| NBM M-M<br>R08-M18                                         |     | NIPPEL MANN.-MANN. BSPP 1/2" - M18 |
| NBM M-M<br>R08-M20                                         |     | NIPPEL MANN.-MANN. BSPP 1/2" - M20 |
| NBM M-M<br>R08-M22                                         |     | NIPPEL MANN.-MANN. BSPP 1/2" - M22 |
| NBM M-M<br>R08-M27                                         |     | NIPPEL MANN.-MANN. BSPP 1/2" - M27 |
| NBM M-M<br>R04-M12                                         |     | NIPPEL MANN.-MANN. BSPP 1/4" - M12 |
| NBM M-M<br>R04-M14                                         |     | NIPPEL MANN.-MANN. BSPP 1/4" - M14 |
| NBM M-M<br>R04-M16                                         |     | NIPPEL MANN.-MANN. BSPP 1/4" - M16 |
| NBM M-M<br>R04-M18                                         |     | NIPPEL MANN.-MANN. BSPP 1/4" - M18 |
| NBM M-M<br>R04-M20                                         |     | NIPPEL MANN.-MANN. BSPP 1/4" - M20 |
| NBM M-M<br>R04-M22                                         |     | NIPPEL MANN.-MANN. BSPP 1/4" - M22 |
| NBM M-M<br>R02-M10                                         |     | NIPPEL MANN.-MANN. BSPP 1/8" - M10 |
| NBM M-M<br>R02-M12                                         |     | NIPPEL MANN.-MANN. BSPP 1/8" - M12 |
| NBM M-M<br>R02-M14                                         |     | NIPPEL MANN.-MANN. BSPP 1/8" - M14 |
| NBM M-M<br>R12-M22                                         |     | NIPPEL MANN.-MANN. BSPP 3/4" - M22 |
| NBM M-M<br>R12-M26                                         |     | NIPPEL MANN.-MANN. BSPP 3/4" - M26 |
| NBM M-M<br>R12-M27                                         |     | NIPPEL MANN.-MANN. BSPP 3/4" - M27 |
| NBM M-M<br>R12-M30                                         |     | NIPPEL MANN.-MANN. BSPP 3/4" - M30 |
| NBM M-M<br>R06-M12                                         |     | NIPPEL MANN.-MANN. BSPP 3/8" - M12 |
| NBM M-M<br>R06-M14                                         |     | NIPPEL MANN.-MANN. BSPP 3/8" - M14 |
| NBM M-M<br>R06-M16                                         |     | NIPPEL MANN.-MANN. BSPP 3/8" - M16 |
| NBM M-M<br>R06-M18                                         |     | NIPPEL MANN.-MANN. BSPP 3/8" - M18 |
| NBM M-M<br>R06-M20                                         |     | NIPPEL MANN.-MANN. BSPP 3/8" - M20 |

|                    |  |                                    |
|--------------------|--|------------------------------------|
| NBM M-M<br>R06-M22 |  | NIPPEL MANN.-MANN. BSPP 3/8" - M22 |
|--------------------|--|------------------------------------|