



Gelieve de webshop te gebruiken om uw bestelling door te sturen

Departement: (Inschroef)nippel Mann.-Mann. BSP-Metr. - CEA			
Nr	Atl	Omschrijving	
NBM M-M R16-M38		NIPPEL MANN.-MANN. BSPP 1" - M38	NBM M-M R08-M14
	NIPPEL MANN. - MANN. BSPP 1/2" - M14	NBM M-M R08-M16	
NIPPEL MANN. - MANN. BSPP 1/2" - M16	NBM M-M R08-M18		NIPPEL MANN. - MANN. BSPP 1/2" - M18
NBM M-M R08-M20		NIPPEL MANN.-MANN. BSPP 1/2" - M20	NBM M-M R08-M22
	NIPPEL MANN. - MANN. BSPP 1/2" - M22	NBM M-M R08-M27	
NIPPEL MANN. - MANN. BSPP 1/2" - M27	NBM M-M R04-M12		NIPPEL MANN. - MANN. BSPP 1/4" - M12
NBM M-M R04-M14		NIPPEL MANN.-MANN. BSPP 1/4" - M14	NBM M-M R04-M16
	NIPPEL MANN. - MANN. BSPP 1/4" - M16	NBM M-M R04-M18	
NIPPEL MANN. - MANN. BSPP 1/4" - M18	NBM M-M R04-M20		NIPPEL MANN. - MANN. BSPP 1/4" - M20
NBM M-M R04-M22		NIPPEL MANN.-MANN. BSPP 1/4" - M22	NBM M-M R02-M10
	NIPPEL MANN. - MANN. BSPP 1/8" - M10	NBM M-M R02-M12	
NIPPEL MANN. - MANN. BSPP 1/8" - M12	NBM M-M R02-M14		NIPPEL MANN. - MANN. BSPP 1/8" - M14

NBM M-M R12-M22		NIPPEL MANN.-MANN. BSPP 3/4" - M22	NBM M-M R12-M26
	NIPPEL MANN. - MANN. BSPP 3/4" - M26	NBM M-M R12-M27	
NIPPEL MANN. - MANN. BSPP 3/4" - M27	NBM M-M R12-M30		NIPPEL MANN. - MANN. BSPP 3/4" - M30
NBM M-M R06-M12		NIPPEL MANN.-MANN. BSPP 3/8" - M12	NBM M-M R06-M14
	NIPPEL MANN. - MANN. BSPP 3/8" - M14	NBM M-M R06-M16	
NIPPEL MANN. - MANN. BSPP 3/8" - M16	NBM M-M R06-M18		NIPPEL MANN. - MANN. BSPP 3/8" - M18
NBM M-M R06-M20		NIPPEL MANN.-MANN. BSPP 3/8" - M20	NBM M-M R06-M22