



Gelieve de webshop te gebruiken om uw bestelling door te sturen

| Departement: Inschroefadapter 90° BSPT M. - JIC M. - DAJ |     |                                                    |
|----------------------------------------------------------|-----|----------------------------------------------------|
| Nr                                                       | Atl | Omschrijving                                       |
| NCJ90 M-M<br>RK16-J12                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1 - JIC 3/4      |
| NCJ90 M-M<br>RK16-J14                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1 - JIC 7/8      |
| NCJ90 M-M<br>RK16-J17                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1" - JIC 1"1/16  |
| NCJ90 M-M<br>RK16-J21                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1" - JIC 1"5/16  |
| NCJ90 M-M<br>RK16-J26                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1" - JIC 1"5/8   |
| NCJ90 M-M<br>RK24-J26                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/2 -JIC 1"5/8 |
| NCJ90 M-M<br>RK24-J30                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/2 -JIC 1"7/8 |
| NCJ90 M-M<br>RK20-J26                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/4 -JIC 1"5/8 |
| NCJ90 M-M<br>RK20-J30                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/4 -JIC 1"7/8 |
| NCJ90 M-M<br>RK20-J17                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/4-JIC 1"1/16 |
| NCJ90 M-M<br>RK20-J21                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/4-JIC 1"5/16 |
| NCJ90 M-M<br>RK08-J17                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/2 - JIC 1"1/16 |
| NCJ90 M-M<br>RK08-J12                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/2 - JIC 3/4    |
| NCJ90 M-M<br>RK08-J07                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/2 - JIC 7/16   |
| NCJ90 M-M<br>RK08-J14                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/2 - JIC 7/8    |
| NCJ90 M-M<br>RK08-J09                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/2 - JIC 9/16   |
| NCJ90 M-M<br>RK04-J08                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 1/2    |
| NCJ90 M-M<br>RK04-J12                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 3/4    |
| NCJ90 M-M<br>RK04-J07                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 7/16   |
| NCJ90 M-M<br>RK04-J14                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 7/8    |
| NCJ90 M-M<br>RK04-J09                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 9/16   |
| NCJ90 M-M<br>RK02-J08                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/8 - JIC 1/2    |
| NCJ90 M-M<br>RK02-J12                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/8 - JIC 3/4    |
| NCJ90 M-M<br>RK02-J07                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/8 - JIC 7/16   |
| NCJ90 M-M<br>RK02-J09                                    |     | INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/8 - JIC 9/16   |

|                       |  |                                                    |
|-----------------------|--|----------------------------------------------------|
| NCJ90 M-M<br>RK32-J30 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 2" - JIC 1"7/8   |
| NCJ90 M-M<br>RK32-J40 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 2" - JIC 2"1/2   |
| NCJ90 M-M<br>RK12-J17 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/4 - JIC 1"1/16 |
| NCJ90 M-M<br>RK12-J19 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/4 - JIC 1"3/16 |
| NCJ90 M-M<br>RK12-J21 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/4 - JIC 1"5/16 |
| NCJ90 M-M<br>RK12-J12 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/4 - JIC 3/4    |
| NCJ90 M-M<br>RK12-J14 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/4 - JIC 7/8    |
| NCJ90 M-M<br>RK06-J08 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/8 - JIC 1/2    |
| NCJ90 M-M<br>RK06-J12 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/8 - JIC 3/4    |
| NCJ90 M-M<br>RK06-J07 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/8 - JIC 7/16   |
| NCJ90 M-M<br>RK06-J14 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/8 - JIC 7/8    |
| NCJ90 M-M<br>RK06-J09 |  | INSCHR.NIPP. 90° MANN.-MANN. BSPT 3/8 - JIC 9/16   |