



Gelieve de webshop te gebruiken om uw bestelling door te sturen

Departement: Inschroefadapter 90° BSPT M. - JIC M. - DAJ			
Nr	Atl	Omschrijving	
NCJ90 M-M RK16- J12		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1 - JIC 3/4	NCJ90 M-M RK16- J14
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 1 - JIC 7/8	NCJ90 M-M RK16-J17	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 1" - JIC 1"1/16	NCJ90 M-M RK16- J21		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1" - JIC 1"5/16
NCJ90 M-M RK16- J26		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1" - JIC 1"5/8	NCJ90 M-M RK24- J26
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 1"1/2 - JIC 1"5/8	NCJ90 M-M RK24-J30	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 1"1/2 - JIC 1"7/8	NCJ90 M-M RK20- J26		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/4 -JIC 1"5/8
NCJ90 M-M RK20- J30		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1"1/4 -JIC 1"7/8	NCJ90 M-M RK20- J17
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 1"1/4- JIC 1"1/16	NCJ90 M-M RK20-J21	

INSCHR. NIPP. 90° MANN. - MANN. BSPT 1"1/4 - JIC 1"5/16	NCJ90 M-M RK08- J17		INSCHR.NIPP. 90° MANN. -MANN. BSPT 1/2 - JIC 1"1/16
NCJ90 M-M RK08- J12		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/2 - JIC 3/4	NCJ90 M-M RK08- J07
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 1/2 - JIC 7/16	NCJ90 M-M RK08-J14	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 1/2 - JIC 7/8	NCJ90 M-M RK08- J09		INSCHR.NIPP. 90° MANN. -MANN. BSPT 1/2 - JIC 9/16
NCJ90 M-M RK04- J08		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 1/2	NCJ90 M-M RK04- J12
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 1/4 - JIC 3/4	NCJ90 M-M RK04-J07	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 1/4 - JIC 7/16	NCJ90 M-M RK04- J14		INSCHR.NIPP. 90° MANN. -MANN. BSPT 1/4 - JIC 7/8
NCJ90 M-M RK04- J09		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/4 - JIC 9/16	NCJ90 M-M RK02- J08
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 1/8 - JIC 1/2	NCJ90 M-M RK02-J12	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 1/8 - JIC 3/4	NCJ90 M-M RK02- J07		INSCHR.NIPP. 90° MANN. -MANN. BSPT 1/8 - JIC 7/16
NCJ90 M-M RK02- J09		INSCHR.NIPP. 90° MANN.-MANN. BSPT 1/8 - JIC 9/16	NCJ90 M-M RK32- J30

	INSCHR. NIPP. 90° MANN. - MANN. BSPT 2" - JIC 1"7/8	NCJ90 M-M RK32-J40	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 2" - JIC 2"1/2	NCJ90 M-M RK12- J17		INSCHR.NIPP. 90° MANN. -MANN. BSPT 3/4 - JIC 1"1/16
NCJ90 M-M RK12- J19		INSCHR.NIPP. 90° MANN. -MANN. BSPT 3/4 - JIC 1"3/16	NCJ90 M-M RK12- J21
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 3/4 - JIC 1"5/16	NCJ90 M-M RK12-J12	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 3/4 - JIC 3/4	NCJ90 M-M RK12- J14		INSCHR.NIPP. 90° MANN. -MANN. BSPT 3/4 - JIC 7/8
NCJ90 M-M RK06- J08		INSCHR.NIPP. 90° MANN. -MANN. BSPT 3/8 - JIC 1/2	NCJ90 M-M RK06- J12
	INSCHR. NIPP. 90° MANN. - MANN. BSPT 3/8 - JIC 3/4	NCJ90 M-M RK06-J07	
INSCHR. NIPP. 90° MANN. - MANN. BSPT 3/8 - JIC 7/16	NCJ90 M-M RK06- J14		INSCHR.NIPP. 90° MANN. -MANN. BSPT 3/8 - JIC 7/8